

Knabenshue Collection - Reports

Extracted on Apr-24-2024 05:05:44

The Smithsonian Institution thanks all digital volunteers that transcribed and reviewed this material. Your work enriches Smithsonian collections, making them available to anyone with an interest in using them.

The Smithsonian Institution (the "Smithsonian") provides the content on this website (transcription.si.edu), other Smithsonian websites, and third-party sites on which it maintains a presence ("SI Websites") in support of its mission for the "increase and diffusion of knowledge." The Smithsonian invites visitors to use its online content for personal, educational and other non-commercial purposes. By using this website, you accept and agree to abide by the following terms.

- If sharing the material in personal and educational contexts, please cite the Smithsonian National Air and Space
 Museum Archives as source of the content and the project title as provided at the top of the document. Include
 the accession number or collection name; when possible, link to the Smithsonian National Air and Space
 Museum Archives website.
- If you wish to use this material in a for-profit publication, exhibition, or online project, please contact Smithsonian National Air and Space Museum Archives or transcribe@si.edu

For more information on this project and related material, contact the Smithsonian National Air and Space Museum Archives. See this project and other collections in the Smithsonian Transcription Center.

6 REPORT NATIONAL ADVISORY COMMITTEE FOR AERONAUTICS

airplane—continued.

pusher airplane—An airplane with the propeller or propellers aft of the main supporting surfaces.

tailless airplane—An airplane in which the devices used to obtain stability and control are incorporated in the wing.

tractor airplane—An airplane with the propeller or propellers forward of the main supporting surfaces.

airport—A tract of land or water which is adapted for the landing and take-off of aircraft and which provides facilities for their shelter, supply, and repair, a place used regularly for receiving or discharging passengers or cargo by air.

air scoop—A scoop or hood designated to catch the air and maintain the air pressure in ballonets, internal-combustion engines, ventilators, etc. (See fig. 3)

airship—An aerostat provided with a propelling system and with means of controlling the direction of motion.

nonrigid airship—An airship whose form is maintained by the internal pressure in the gas bags and ballonets (fig. 3).

pressure-rigid airship—An airship combining the principled used in both rigid and nonrigid airships to maintain shape and skin tautness. rigid airship—An airship whose form is maintained by a rigid structure (fig. 6).

semirigid airship—An airship whose shape is maintained by means of a rigid or jointed keel in conjunction with internal pressure in the gas containers and ballonets (fig. 4).

airship shed—See DOCK

airship station—(1) The complete assembly of sheds, masts, gas plants, shops, landing fields, and other equipment required to operate airships and supply their needs. (2) The base from which airships are operated.

air speed—The speed of an aircraft relative to the air.

air-speed head—An instrument which, in combination with a gage, is used to measure the speed of an aircraft relative to the air. It usually consists of a pilot-static tube or a pilot-venturi tube.

air volume—See AERODYNAMIC VOLUME.

airway—An air route along which aids to air navigation, such as landing fields, beacon lights, radio direction-finding facilities, intermediate fields, etc., are maintained.

airworthiness—The quality of an aircraft denoting its fitness and safety for operation in the air under normal flying conditions.

altigraph—A recording altimeter.

altimeter—An instrument that measures the elevation of an aircraft

REPORT NATIONAL ADVISORY COMMITTER FOR ASSESSAUTION

sirplane-continued.

pusher sirplane—An eirplane with the propoller or propolers and of the main supporting surfaces. Indition simplane—An airplaned in which the devices meet to obtain studdity and control are inresponsible in the wing.

tractor sitplane—An siplene with the propoller or propollers forward of the main supporting uniform.

strpert—A tract of land or water which is adapted for the harding and take-off of sizeralt and which provides facilities for their shelter, supply, and repair, a place used regularly for receiving or disducing passengers or early by air.

sit strony—A recop or hood dissipand to canch the sir and maintain the sir pressure in hallouses, internal-condustion engines, resultation, etc. (So fig. 3.) similay—An acrostst provided with a propelling system and with means of controlling the direction of

noticed and process of the process of the protained by the internal pressure in the gas bags and ballancies (fig. 2).

present rigid atritip—In sinhip containing the principles used in both rigid and sourgid sinships to maintain shape and skin terriers, rigid atritip—An sinkip whose form is main-

taked by a rigid structure (fig. 6), sensingid simble—An mindle whose shape is amintained by means of a rigid or jointed lord to conjunction with internal pressure in the gra-

cretainers and believes (fig. 6). simble shed—See now.

simile station—(1) The complete assembly of shells, musts, one phote, sloops, lending fields, and other equipment required to operate alrelips and supply their mode. (3) The base from which nimbings are operated.

air speed.—The speed of on aircraft relative to the air, air-speed head—An instrument which, in conditiontion with a gap, in most to measure the speed or aircraft relative to the air. It testelly common of a pitch-static take or a pitch-execute take.

air solume. See amoust same volume.

airway—An eir reute along which aide to air maxigation, such as harding fields, beacon lights, racks direction-finding facilities, intermediate fields, ctr., are maintained.

sireorthiese.—The quality of an aircraft denoting its fitness and safety for operation in the air under normal fiving conditions.

sitigraph—A recentling altituates.

altimeter—An instrument that measures the devation of an alresult above a given datura plane, altitude.

absolute attitude. The height of an aircraft above the earth.

altitude-restinged

entical sittings—The maximum shitteds at which a capercharger can maintain a pressure in the matter manifold of an ongine event to that existing farriag normal operation of rated power and spend at see level.

density shinele—The altitude corresponding to a given density in a standard atmosphere, presents shinele—(1) The altitude correspond-

presents attends—(1) The allitude corresponding to a given pressure in a standard atmosphere. (2) The allitude at which the gas bugs of an allitude become [all.

attitude misture control-Son mintens coloreda,

smphiMan—An airplane designed to rice from and alight on either land or water.

alleres single. The angular displacement of an alleres from its neutral position. It is positive when the trailing edge of the alleres is below the neutral position.

the resurns position.

Made angle—The scate angle between the chard at
a section of a propelletter of a ratary wing system,
and a plane percenticular to the axis of retailer.

cuting angle—The average angle between the spen axis of a blade or wing of a covery wing system and a place perpendicular to the axis of retailer.

dishelfs aggle—The states angle between a like perpendicular to the plans of symmetry and live projection of the wing side on a plane perpendicular to the longitudinal axis of the significant. If the wing axis is not appreximately a straight live, the angle is measured from the projection of a fire joining the latteraction of the wing only with the plane of symmetry, and the scenarionantic center of the bull-wing on either side of the plane of symmetry. (See fig. 5.)

downwesh angle.—The angle through which on air stream is deflected by any lifting norface. It is measured in a plane parallel to the phase of symmetry.

drift angle—The berisantal angle between the lengitudinal axis of an aircraft and its goth relative to the ground.

effective halix angle—The angle of the belix doubled by a particular point on a propeller blade as the sirplane moves forward through air observine uncistarbed.

elevator angle.—The angular displacement of the elevator from its neutral position. It is prestive when the trailing edge of the elevator is below the neutral position.

below the neutral position, fapping angle—The difference between the consign sugle and the instrumences angle of the span axis of a blade of a ratery wing quaters relative to the plane perpendicular to the axis of rotation. above a given datum plane.

altitude:

absolute altitude—The height of an aircraft above the earth. altitude—continued.

critical altitude—The maximum altitude at which a supercharger can maintain a pressure in the intake manifold of an engine equal to that existing during normal operation at rated power and speed at sea level. density altitude—The altitude corresponding to a given density in a

standard atmosphere.

pressure altitude—(1) The altitude corresponding to a given pressure in a standard atmosphere. (2) The altitude at which the gas bags of an airship become full.

altitude mixture control—See MIXTURE CONTROL, ALTITUDE.

amphibian—An airplane designed to rise from and alight on either land or water.

angle:

aileron angle—The angular displacement of an aileron from its neutral position. It is positive when the trailing edge of the aileron is below the neutral position.

blade angle—The acute angle between the chord of a section of a propeller, or of a rotary wing system, and a plane perpendicular to the axis of rotation.

coning angle—The average angle between the span axis of a blade or wing of a rotary wing system and a plane perpendicular to the axis of rotation.

dihedral angle—The acute angle between a line perpendicular to the plane of symmetry and the projection of the wing axis on a plane perpendicular to the longitudinal axis of the airplane. If the wing axis is not approximately a straight line, the angle is measured from the projection of a line joining the intersection of the wing axis with the plane of symmetry and the aerodynamic center of the half-wing on either side of the plane of symmetry. (see fig. 5)

downwash angle—The angle through which an air stream is deflected by any lifting surface. It is measured in a plane parallel to the plane of symmetry.

drift angle—The horizontal angle between the longitudinal axis of an aircraft and its path relative to the ground.

effective helix angle—The angle of the helix described by a particular point on a propeller blade as the airplane moves forward through air otherwise undisturbed.

elevator angle—The angular displacement of the elevator from its neutral position. It is positive when the trailing edge of the elevator is below the neutral position.

flapping angle—The difference between the coning angle and the instantaneous angle of the span axis of a blade of a rotary wing system relative to the plane perpendicular to the axis of rotation.

Knabenshue Collection - Reports Transcribed and Reviewed by Digital Volunteers Extracted Apr-24-2024 05:05:44



Smithsonian Institution

Smithsonian National Air and Space Museum Archives

The mission of the Smithsonian is the increase and diffusion of knowledge - shaping the future by preserving our heritage, discovering new knowledge, and sharing our resources with the world. Founded in 1846, the Smithsonian is the world's largest museum and research complex, consisting of 19 museums and galleries, the National Zoological Park, and nine research facilities. Become an active part of our mission through the Transcription Center. Together, we are discovering secrets hidden deep inside our collections that illuminate our history and our world.

Join us!

The Transcription Center: https://transcription.si.edu
On Facebook: https://www.facebook.com/SmithsonianTranscriptionCenter

On Twitter: @TranscribeSI

Connect with the Smithsonian Smithsonian Institution: www.si.edu

On Facebook: https://www.facebook.com/Smithsonian

On Twitter: @smithsonian